

YOUR MUSIC. YOUR POWER.

OWNER'S MANUAL 400.4 EVOX2



Introduction	٦	З
Package c	ontents	З
Safety instr	ructions	4
Technolog	ies	
	DTM [®]	5
	Ultra Compact PCB	5
	Robust Construction	5
	I-Power Supply	5
	Full Range	6
Assembling	g and Disassembling the plastic cover	7
Panels des	cription	
	Audio inputs and controls	8
	Power inputs and audio outputs	9
Installation	sequence	10
Electrical D	imensioning	11
Audio input	ts	
	RCA inputs	11
	High Level inputs	11
Wiring diag	ram	
	Four channels wiring diagram	12
	Three channels wiring diagram	12
	Two channels wiring diagram and Gain Setting	13
Procedure	for setting the gain	13
Crossovers	s set up	14
Technical s	pecifications	
	Parameters	15
	Dimensional data	15

DEAR CUSTOMER,

CONGRATULATIONS ON ACQUIRING A PRODUCT WITH THE HIGHEST QUALITY AND TECHNOLOGY!

You have just purchased a **SounDigital** product of the highest technology and quality, so we thank you for your confidence.

SounDigital products are made with raw materials of the highest quality standards, and the most modern processes, equipment and technology are used in their production.

On this manual you will learn about the product, its features and characteristics, in order to obtain the best result and to be able to enjoy your music with **SounDigital** quality and power.

To better understand and take advantage of all the functions of the product and use it safely, read this manual carefully and if you have any questions, consult our support by email **info@soundigitalusa.com**.

PACKAGE CONTENTS

- 01 400.4 EVOX2 Amplifier
- 01 Installation quick guide with warranty card
- 01 Allen wrench 2.0mm
- 02 Cables for high level input
- 01 Promotional sticker

To prevent injuries to the user or damage to the amplifier, read all safety instructions written on this manual;

If you are insecure about the installation of this equipment, get in touch with our tech support or with a professional specialized in car audio installation;

Before proceeding with the installation of any electric equipment on your vehicle, unplug the negative (-) terminal of the battery to avoid fires, injuries or damages;

Use your sound system safely. The continuous exposure to sound pressures over 85dB may cause irreversible hearing damage;

This equipment is for use in automotive DC voltage batteries between 12.6 and 14.4 volts. Before installing the equipment, check voltage of the batteries;

Do not install the amplifier in places exposed to water, dirt or humidity;

Choose a ventilated place to install the amplifier and avoid blocking the side ventilation windows;

Mount the amplifier in a secure way. Avoid mounting it on metallic parts of the vehicle, because it may cause ground looping (noise);

Make sure that the location chosen for the amplifier installation does not effect the operation of the vehicle;

When passing cables through metallic walls, use rubber O-rings to avoid cable cutting and short-circuits;

Clean the amplifier periodically with brush or dry cloth to assure the thermal efficiency of the heatsink;

This product may reach temperatures over 60°C/140°F. Make sure it is cold before touching it;

Be careful when making holes in the vehicle. Make sure you are not making holes in the fuel tank, brake lines or electrical cables of the vehicle;


Make sure the cables are properly secured throughout the installation;

Wear gloves, safety glasses and and all necessary PPE during the installation of SounDigital amplifiers.



THIS "WARNING" SIGN ALERTS THE USER OF IMPORTANT INFO. NOT FOLLOWING THIS INSTRUCTIONS MAY CAUSE INJURIES TO THE USER OR DAMAGE TO THE EQUIPMENT.

DYNAMIC THERMAL MANAGEMENT - DTM®



The **DTM**^{*} is a dynamic thermal recovery system which always maintains a high efficiency of the amplifier by accelerating the thermal exchange of electronic components with the heatsink.


* Patent. Required

ULTRA COMPACT PCB

An intelligent layout, with great use of the PCB area and the use of modern components with reduced structure guarantee **SounDigital** products a compact design, at the same time robust and with excellent thermal efficiency.

ROBUST CONSTRUCTION

Thinking about the application of power sports, the product has an extremely robust assembly, both the fixing points and the layout of the PCB were designed to withstand high vibrations, bumps and impacts.




I-POWER SUPPLY

SounDigital amplifiers are known for their low consumption of battery, and this feature was improved on the **EVOX2 Line**. The new **I-POWER SUPPLY** is even more modern, which replaces the old toroidal transformers by a new generation of "E-E" core transformers delivers efficiency above 90%*, ensuring more hours of sound without battery recharge.

*Efficiency measured at power supply only






VIBRATION ABSORPTION DEVICE - VAD[®]

Our VAD[®] Technology reduces all impact caused by vibration on the electronic circuit board. This can include road vibration and even vibration caused by sound waves, increasing the reliability of our amplifiers.

REDUCED SIZE

The technology used in our amplifiers bring both high performance and power a compact chassis, providing flexible installation solutions for vehicles with limited space.






FULL RANGE


Versatile products that cover the entire audible frequency range, any type of loudspeaker or music program. The plastic covers have the function of finishing and hiding the amplifier fixing screws. To disassembling and assembling them, follow the instructions below.

DISASSEMBLING OF THE PLASTIC COVER




*Merely illustrative images.


ASSEMBLING THE PLASTIC COVER



*Merely illustrative images.



1	CH1/CH2	Variable crossover control — 45Hz ~ 850Hz	
2	CH3/CH4	Valiable crossover control – 45 12 × 650 12	
З	CH1/CH2	Audio inputs — High Level	
4	CH3/CH4	(To connect to the speaker output of the head unit)	
5	CH1		
6	CH2	Audio inputs — RCA connectors	
7	CH3		
8	CH4		
9	CH1/CH2	Crossover Switch	
10	CH3/CH4	Low Pass - Full - High Pass	
11	CH1/CH2	Variable Gain Control	
12	CH3/CH4		



13	CH1	Positive speaker connector
14	CH1	Negative speaker connector
15	CH2	Positive speaker connector
16	CH2	Negative speaker connector
17	СНЗ	Positive speaker connector
18	СНЗ	Negative speaker connector
19	CH4	Positive speaker connector
20	CH4	Negative speaker connector
21	-	Positive power supply connector (+12VDC)
22	-	Remote power supply connector (REM)
23	-	Negative power supply connector (GND)
24	-	"Power ON" LED indicator (Blue)




BEFORE PROCEEDING WITH THE INSTALLATION, UNPLUG THE NEGATIVE TERMINAL FROM ALL OF THE BATTERIES, TO AVOID FIRE, DAMAGE TO THE AMPLIFIER AND THE Warning! USER HIMSELF.

- Mount the amplifier in such a way you have access to the connectors; \geq
- Install the power cables in the vehicle properly, starting from the battery to the fuse \geq holder or circuit breaker, use the cable with the appropriate size. Make all connections, install fuse holders or circuit breakers, but without placing the fuses or with the circuit breakers in the "OFF" position;



THE MAXIMUM DISTANCE FOR THE INSTALLATION OF THE FUSE/CIRCUIT BREAKER IS 12 INCHES (30cm) AWAY FROM THE BATTERY. Warning!

- \geq Connect the power cables in to the amplifier, observing the polarity. Connect all the positive cables from the fuse holder or circuit breaker to the positive conector of the amplifier and all the negative power cables from the batteries to the negative connector of the amplifier;
- \geq The ground cable must be as short as possible and must be connected to the vehicle chassis and the battery negative;



- Install the signal input cables in a proper way, distant from the power cables; \geq
- \geq Connect the RCA or the high level signal input cables to the head unit and amplifiers;
- Install the audio output cables with the appropriate section, distant from the power \geq and audio input cables;
- Connect the audio output cables to the amplifier and speakers respecting the \geq positive (+) and negative (-) polarities;
- Install the remote cable with the power cables, using 1.5mm² (15 AWG) cable or \geq thicker:
- Connect the remote power cable to the amplifier's "REM" terminal at the main unit's remote power output (when not using the high level signal inputs);
- Before powering the system, verify all the connections and make sure there are no \triangleright mistakes or short-circuits on the power and ground cables;
- Reconnect the ground of the batteries; \geqslant
- Check if the head unit is turned off and then place the fuses in the fuse holders or \geq switch the circuit breakers on;
- Turn on the main unit and the amplifier will turn on the "ON" LED indicating that it is \geq in operation.

ELECTRICAL DIMENSIONING

For proper operation of your SounDigital amplifier, you need the proper dimensioning of the electrical system and the cables used.


The table below shows the minimum section of GND cables, +12VDC cables and speaker output cables according to the power generated by the amplifier.

400 WRMS	POWER CABLE GROUND CABLE	10mm² - 8 AWG
VIRIVIS	SPEAKER CABLE	2 x 1.5mm² - 15 AWG

We recommend the use of ONLY OFC (Oxygen Free Copper) Cables on the installation of our products.


AUDIO INPUTS

RCA inputs



A fo

All RCA Inputs must be connected for the all channels to work properly.



High level signal inputs

High level input must be used when the main unit does not have RCA outputs.


When High level inputs is used, no remote connection is required, the amplifier recognizes the audio signal and switches on.

If your source unit is not able to turn on the amplifier through the High level input, the remote input should be connected normally.




RCA AND HIGH LEVEL INPUTS SHOULD NOT BE USED SIMULTANEOUSLY OR YOU MAY DAMAGE THE AMPLIFIER.


4 CHANNELS WIRING DIAGRAM



3 CHANNELS WIRING DIAGRAM



2 CHANNELS WIRING DIAGRAM



GAIN SETTING

Necessary equipament:

- > Digital AC voltmeter;
- Media with sine wave test tone 60Hz recorded at 0db;
- > Screwdriver 1/8" (for gain set);


Set up procedure

- > This procedure is the same for both gain controls;
- > Turn the gain control all the way down;
- Disconnect the output cables from the amplifier outputs;
- > Turn off all processing (bass, treble, loudness, EQ, etc.);
- Set the source unit volume to 3/4 of full volume;

- > On the CD player, set the fader control to center position;
- > Set the crossover selector switch in "F";
- > Use a 60 Hz sine wave;
- Connect the AC voltmeter to the speaker output connectors of the amplifier. Make sure you test the voltage at the correct connectors (+ and -);
- Increase the gain control until the target voltage is observed with the voltmeter (see the chart below);
- Once you have adjusted the amplifier to its correct voltage output, turn off the source unit and reconnect the speaker(s).


Download the tracks for set up in https://soundigitalusa.com/tracks-for-set-up/

MODEL	STEREO / POWER	BRIDGE / POWER	STEREO OUTPUT VOLTAGE	BRIDGE OUTPUT VOLTAGE
400.4 EVOX2	2Ω / 100W	4Ω / 200W	14.14 V	28.3 V




"F" All the frequencies are reproduced; "LP " Set in the variable control on Low Pass Function; "HP " Set in the variable control on High Pass Function.


> Change the switch to "F" position (Full Range): All the frequencies are reproduced.



Change the switch to "HP" position - Set in the variable control between 45Hz and 850Hz ("A") where you want to perform the high pass cut filter;



> Change the switch to "LP" position - Set in the variable control between 45Hz and 850Hz ("B") where you want to perform the low pass cut filter;



PARAMETERS	400.4 EVOX ₂
Power RMS @ 4Ω**	4 x 66W
Power RMS @ 20**	4 x 100W
Power RMS (Bridge) @ 8Ω**	2 x 132W
Power RMS (Bridge) @ 4Ω**	2 x 200W
Frequency Response (-3dB)	5Hz ~ 22kHz
Low Pass filter (12dB/oct.)	45Hz ~ 850Hz
High Pass filter (12dB/oct.)	45Hz ~ 850Hz
Operating Voltage	8V ~ 16V
SNR	96dB
Input Sensitivity (RCA)	0.2 ~ 2V
Input Sensitivity (High Level input)	1.5V ~ 15V
Current Draw (music)	17A
Current Draw (max.)	34A
Current Draw (max.) Total Efficiency	34A 83%
	-
Total Efficiency	83%
Total Efficiency Damping Factor	83% 200
Total Efficiency Damping Factor Power Cable	83% 200 10mm² (8 AWG)
Total Efficiency Damping Factor Power Cable Speaker Cable	83% 200 10mm² (8 AWG) 2 x 1.5mm² (15 AWG)


*It is mandatory to install the fuse at a maximum distance of 12 inches from the battery.

**Power at 14.4V @ 60Hz with a maximum THD of 1%.



**POWER RATING ACCORDING TO CTA-2006 INDUSTRY STANDARDS.

DIMENSIONAL DATA





YOUR MUSIC. YOUR POWER.













